


BYGGFLÄKT 3 kW

PRODUKTBESKRIVNING

Detta är en elektrisk byggfläkt. För säker användning har den en termostat som stänger av värmeelementet om överhettning skulle inträffa. Fläkten kontrolleras inte av termostaten. Om termostaten stänger av värmeelementet fortsätter fläkten ändå att gå.

KONTROLLPANEL



FÖRSIKTIGHET! Vissa delar av denna produkt kan bli mycket heta och orsaka brännskador. Särskild uppmärksamhet måste ägnas åt barn och utsatta människor.

INSTRUKTION FÖR THERMOSTAT

1. Ställ funktionsvredet på önskat effektläge.
2. Vrid termostaten till "MAX"-läge.
3. Låt enheten gå på vald effekt tills temperaturen i rummet nått önskad nivå.
4. Vrid termostaten moturs tills du hör att värmeslingan slås av.

Termostaten kommer nu att slå på och av värmeslingan automatiskt beroende på inställt värde för att hålla en konstant rumstemperatur.

EFTER ANVÄNDNING

1. Vrid termostaten till "MIN"-läge.
2. Vrid funktionsvredet till "Fläkt"-läge.
3. Låt byggfläkten kyla av sig i 2 minuter.
4. Stäng av byggfläkten.

Notera: Vid första användning kan viss rökutveckling uppstå. Det är helt normalt och slutar efter en kort stund. Denna produkt är endast lämpad för välisolerade utrymmen eller sporadisk användning.

SÄKERHETSINSTRUKTIONER

VARNING! För att undvika överhettning får byggfläkten aldrig täckas över.

Vid användning av elektriska apparater ska grundläggande försiktighetsåtgärder alltid följas, till exempel följande:

1. Får bara kopplas till säkring på mer än 16 A.
2. Använd inte utomhus eller på fuktiga platser. Använd aldrig apparaten i badrum, duschar eller nära pooler etc.
3. Koppla ur apparaten från strömuttaget om den inte ska användas på ett tag.
4. Ställ inte apparaten så att framsidan står nära mot en vägg eller ett hörn.
5. När apparaten används, se till att den är långt bort från lättantändliga material, explosivt material eller explosiva gaser.
6. Se till så att anslutningskabeln ligger tillräckligt långt från värmeutblåset.
7. Använd inte apparaten tillsammans med en timer eller annan enhet för automatisk av- och påslagning.
8. Om anslutningskabeln är skadad måste den bytas ut av en kvalificerad person innan användning.
9. Apparaten får ej placeras i anslutning till ett vägguttag.
10. Barn under 3 år bör hållas borta såvida de inte kontinuerligt övervakas.
11. Barn från 3-8 år får endast slå på/stänga av apparaten förutsatt att den har placerats eller installerats i dess avsedda normala driftsläge och de har fått tillsyn eller instruktioner om användning av apparaten på ett säkert sätt och förstår farorna. Barn från 3-8 år får inte ansluta, reglera och rengöra apparaten eller utföra underhåll av användaren.
12. Den här apparaten kan användas av barn från åtta år och uppåt samt av personer med nedsatt fysisk, sensorisk eller mental förmåga eller personer som saknar erfarenhet och kunskap, om de ges handledning eller får instruktioner angående en säker användning av apparaten och förstår de risker som är förknippade med användningen. Barn får inte leka med apparaten. Rengöring och underhåll får inte utföras av barn utan övervakning.

FÖRSIKTIGHET - Vissa delar av denna produkt kan bli mycket heta och orsaka brännskador. Särskild uppmärksamhet måste ägnas åt barn och utsatta människor.



BYGGFLÄKT 3 KW

RENGÖRING OCH UNDERHÅLL

Koppla ur apparaten från strömuttaget och låt den svalna innan rengöring. Var försiktig så att vatten inte hamnar inuti apparaten. Skölj inte apparaten med vatten. När du ska ställa undan fläkten, låt den först svalna. Ställ den sedan på en torr plats.

FELSÖKNING

Problem	Möjlig orsak	Lösning
Apparaten fungerar inte även om den är inkopplad och funktionsvredet och termostaten är korrekt inställda.	Dålig anslutning till strömuttaget.	Dra ur sladden, kontrollera stickproppen och anslut sedan apparaten igen.
	Ingen ström i uttaget.	Koppla in apparaten i ett annat uttag.
Värmeelementet glöder.	För hög eller låg spänning.	Säkerställ att apparaten är inkopplad till rätt spänning som anges på baksidan apparaten.
	Luftintaget är blockerat.	Se till så att apparaten inte är i närheten av gardiner, plastpåsar, papper och liknande som lätt kan dras till och täcka luftintaget.
Apparaten avger ingen värme, bara fläkten fungerar.	Funktionsvredet är inte i rätt läge.	Vrid vredet till rätt läge.
	Termostaten har slagit från värmeelementet.	Vrid termostaten och lyssna efter ett klick-ljud. Om det inte hörs något sådant har överhettningsskyddet slagit till. Värmelementet kommer att slås på så snart apparaten har svalnat något.
Onormalt ljud.	Underlaget är inte jämnt.	Ställ apparaten på ett jämnt underlag.

Art nr Dahl 334031	Art nr Optimera 7357468
Effekt	3 kW
Kabeltyp	H07RN-F 3G1,5 mm²
Kabellängd	1,5 m
Effekt 1	Kalluft
Effekt 2	1500 W
Effekt 3	3000 W
Justerbar termostat	Ja
Märksystem	-
Kapslingsklass	IP24
Spänning	230 V ~ 50 Hz
Mått	305 x 260 x 435 mm
Vikt	5,1 kg



Du kan hjälpa till att skydda miljön. Vänligen följ de lokala bestämmelserna. Lämna tillbaka elektrisk utrustning som inte fungerar till ett lämpligt avfallshanteringscenter. För produkter som innehåller borttagbara batterier: ta bort batterierna innan du kasserar produkten.





FAN HEATER 3 KW

PRODUCT DESCRIPTION

This is an electric heater with ventilator/fan motor. It has a thermostat that will switch off the heater if overheating occurs to ensure safe usage. The fan motor is not controlled by the thermostat. If the thermostat turns off the heating element the ventilator will keep working.

CONTROL PANEL



CAUTION! Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.

THERMOSTAT INSTRUCTIONS

1. Turn the function switch to the desired power position.
2. Turn the thermostat to "MAX"-position.
3. Let the heater operate with chosen power input until the room temperature reaches the required value.
4. Turn the thermostat counterclockwise until you hear the heating coil turn off.

The thermostat will switch on and off automatically to control the room temperature according to the preset value to keep the room temperature constant.

AFTER USE

1. Turn the thermostat to "MIN"-position.
2. Turn the function switch to "Fan"-level".
3. Let the appliance cool down for 2 minutes.
4. Turn the fan heater off.

Note: When using the heater for the first time, you may notice a slight emission of smoke. This is normal and it stops after a short time. This product is only suitable for well insulated spaces or occasional use.

SAFETY INSTRUCTIONS

WARNING! In order to avoid overheating, do not cover the heater.

When using electrical appliances basic precautions should always be followed, including the following:

1. Fuse capacity must be more than 16 A.
2. Do not use outdoors or in humid place. Never use the heater in the bathroom, shower or near a swimming pool etc.
3. When you don't use the appliance for a long time, unplug the appliance.
4. Do not position it closely facing a wall or a corner.
5. When the appliance is in use, keep it far from combustible, explosive articles or explosive, corrosive gas.
6. Keep the power cord far enough away from the hot air outlet.
7. Do not use this heater with a programmer, timer or any other device that switches the heater on automatically.
8. If the supply cord is damaged it must be replaced by a qualified person prior to use.
9. The heater must not be located immediately below a socket-outlet.
10. Children of less than 3 years should be kept away unless continuously supervised.
11. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
12. This appliance can be used by children aged from 8 years and above and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

CAUTION - Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.



FAN HEATER 3 KW

CLEANING AND MAINTENANCE

Before cleaning the appliance, disconnect it from the socket and let it cool down. Be careful not to let the water enter the appliance inner. Do not splash water onto the heater. When you store the heater, let it cool down first then store it in a dry place.

TROUBLE SHOOTING

Problem	Possible cause	Solution
The heater does not operate, even when it is plugged in and the switch and thermostat are switched on.	The plug is loose, bad connection.	Pull out the plug, check the connection of the plug and socket. Then connect again.
	No power in socket outlet.	Insert the plug in a proper socket.
	The input voltage is too high or too low.	Use power supply according to the rating on the label.
The heat element glowing	The air inlet grille is blocked.	Keep the heater far away from articles like curtain, plastic bag, paper and other things which can cover the inlet or can be easily absorbed on the air inlet.
	The switch was not put at heating level.	Turn the switch to heating level.
The appliance didn't heat up, only ventilator worked.	The thermostat operated.	Turn the thermostat and listen if there is open/ close voice. If there is no click and the thermostat is not damaged, the heater will automatic switch on when the appliance cooled down.
	The appliance is not level.	Put the heater on a level surface.
Abnormal noise.		

Art nr Dahl 334031	Art nr Optimera 7357468
Effekt	3 kW
Cable type	H05RN-F 3G1,0 mm ²
Cable length	1,6 m
Effect level 1	Cold air
Effect level 2	1500 W
Effect level 3	3000 W
Adjustable thermostat	Yes
Marking system	-
Protection class (ingress of water)	IP24
Voltage	230V ~ 50 Hz
Measurements	305 x 260 x 435 mm
Weight	5,1 kg



You can help protect the environment. Please respect the local regulations. Return non-working electrical equipments to an appropriate waste disposal center.
For items which contain removable batteries: remove batteries before disposing the product.

