


Installation Guide

Gas detection sensor/B&L (Buzzer & Light) alarm replacement for DGS



AN284530374104en-000201



1. Unplug sensor/B&L (LED → yellow)
2. Unscrew sensor/B&L
3. Install new device in reverse order
4. Await green light in LED