

Service Parts List

No.	Part Code	Part Name	Specification	Quantity
1	80415260R	COMPRESSOR	C-CV753L0U 1000VF8(A)	1
2	80225205116000	PRESSURE SENSOR	HKS-S046	4
3	81425432097000	TERMINAL BASE	POWER SUPPLY 1000VF8(A)	1
4	80223390031000	ADHESIVE LABEL	POWER SUPPLY LABEL 1000VF8(A)	1
5	80225324291000	TERMINAL BASE	CONTROL 400VF8(A)/1000VF8(A)	1
6	80225324306000	TERMINAL BASE	MULTIUSE	3
7	80225324307000	TERMINAL BASE	EXT COM 1000VF8(A)	1
8	77742329696010	RELAY	MC220/240A2-F	3
9	80105334410520	CR2-EN-PCB	1000VF8	1
10	80105334408520	FIL2-EN-PCB	1000VF8(A)	1
11	80105334411520	CR2D-EN-PCB	400VF8(A)/1000VF8(A)	1
12	80205312235000	CONTROL PANEL 400V	INVERTER A1000 1000VF8(A)	1
13	80205312236001	CONTROL PANEL 400V	INVERTER V1000 1000VF8(A)	1
14	80242649600540	SOLENOID VALVE COIL	REACTOR 400VF8(A)/1000VF8(A)	1
15	80242649600550	SOLENOID VALVE COIL	REACTOR V1000 1000VF8(A)	1
16	80225204130000	ROCKER SWITCH	S1	1
17	80205305300000	FAN MOTOR	ELEC BOX FAN MOTOR 1000VF8(A)	1
18	80223412154000	GUARD	ELEC BOX FAN GUARD 1000VF8(A)	1
19	80203530111001	AIR FILTER	AIR FILTER 1000VF8(A)	1
20	77742049602250	TEMP SENSOR	DISCHARGE TEMPERATURE	1
21	77742649600421	SOLENOID VALVE COIL	VALVE COIL MOV1/MOV7	1
22	77742649600430	SOLENOID VALVE COIL	VALVE COIL MOV5/MOV6	2
23	80205202579000	SOLENOID VALVE COIL	VALVE COIL EV2	1
24	1FJ4H1C0082001	CRANK CASE HEATER	1000VF8(A)	1
25	77742049602260	THERMISTOR 0.066W		2
26	77742049602050	THERMISTOR 0.005W		1
27	1FA4M4A0226002	DC MOTOR	MAIN FAN 1000VF8(A)	1
28	85402501326004	FAN	MAIN FAN 1000VF8(A)	1
29	80105313129002	THERMISTOR 0.005W		2
30	80203513187000	FILTER DRYER	DCY-P8 165 S	1
31	80203415662001	PANEL FRONT ASSY	FRONT 1000VF8	1
	80203415662011	PANEL FRONT ASSY	FRONT 1000VF8SL	1
32	80203414263000	PANEL SIDE ASSY	LEFT 1000VF8(A)	1
	80203414263010	PANEL SIDE ASSY	LEFT 1000VF8(A)SL	1
33	80203416236000	PANEL REAR ASSY	REAR BTM 1000VF8(A)	1
	80203416236010	PANEL REAR ASSY	REAR BTM 1000VF8(A)SL	1
34	80203414264000	PANEL SIDE ASSY	RIGHT 1000VF8(A)	1
	80203414264010	PANEL SIDE ASSY	RIGHT 1000VF8SL(A)	1
35	80203414271000	PANEL SIDE ASSY	OUTLET COVER 1000VF8(A)	1
	80203414239010	PANEL SIDE ASSY	OUTLET COVER 1000VF8(A)SL	1
36	80203413827000	PANEL ASSY	REAR TOP 1000VF8(A)	1
	80203413652001	PANEL ASSY	REAR TOP 1000VF8(A)SL	1
37	80223413618001	PANEL	RIGHT TOP 1000VF8(A)	1
	80223413618011	PANEL	RIGHT TOP 1000VF8(A)SL	1
38	80203327775000	MTG PLATE ASSY	1000VF8(A)	1
	80203327775010	MTG PLATE ASSY	1000VF8(A)SL	1
39	80203413715000	PANEL	LEFT TOP 1000VF8(A)	1
	80203413715010	PANEL	LEFT TOP 1000VF8(A)SL	1

Service Parts List


No.	Part Code	Part Name	Specification	Quantity
40	80203412219000	GUARD ASSY	MAIN FAN GRILL 1000VF8(A)	1
41	80203514139000	SUCTION FILTER	S-008T1	1
42	80203514132000	STRAINER		3
43	80203514133000	STRAINER		1
44	80203503394000	VALVE ASSY	VALVE BODY MOV5/MOV6	2
45	80203503369000	VALVE ASSY	VALVE BODY MOV1/MOV3/MOV7	1
46	80203502546000	SERVICE VALVE ASSY	2HP HP/10HP OIL	1
47	80203502543000	SERVICE VALVE ASSY	10HP HP/10HP LP	2
48	80203214909000	TUBE CONNECTOR ASSY	PRS SENSOR PIPE 1000VF8	1
49	80205302799000	COVER ELEC BOX ASSY	1000VF8	1
50	85421106400014	FAN COVER	MAIN FAN COVER 1000VF8(A)	1
51	80223402178000	SUPPORT MOTOR	FM SPT FRT 1000VF8(A)	2
	80223402178010	SUPPORT MOTOR	FM SPT FRT 1000VF8(A)SL	2
52	80223324829000	SUPPORT MOTOR	FM SPT REAR 1000VF8(A)	1
	80223324829010	SUPPORT MOTOR	FM SPT REAR 1000VF8(A)SL	1
53	80203214902000	TUBE CONNECTOR ASSY	EV2 PIPE 1000VF8(A)	1
54	80203214945000	TUBE CONNECTOR ASSY	SERV PORT PIPE 1000VF8(A)	1
55	80203214901000	TUBE CONNECTOR ASSY	PRS SENSOR PIPE 1000VF8	1
56	80203327845000	MTG PLATE ASSY	COMP FIXATION 1000VF8	1
57	80203517115003	LUBRICATING OIL	4L CAN PZ-68S	1
58	80203517117002	LUBRICATING OIL	0.5L BOTTLE PZ-68S	1
61	80203519114002	OIL REGULATOR	OIL LEVEL SENSOR 1000VF8(A)	1
62	80203105509002	GAS COOLER	1000VF8(A)	1
	80203105509022	GAS COOLER	1000VF8(A)SL	1
63	80203511377000	PRESSURE SWITCH		1
64	80203503372000	VALVE ASSY	VALVE BODY EV2	1
65	80203300106001	EXP TANK ASSY	400VF8(A)/1000VF8	1
66	80203518156000	OIL SEPARATOR		1
67	80203317006000	RUBBER GROMMET ASSY		3
	80223317199001	RUBBER GROMMET		3
	80223306198003	COLLAR		3
	803A1080600070	BOLT 8		3
	803C8080000100	WASHER SPRING 8		3
	77739021041001	WASHER		2
	77739280120111	HIWA 12		2
68	80126195114002	CAP TERMINAL COVER	1000VF8(A)	1
	80128926110000	CLIP	COMP COVER 1000VF8(A)	1
69	80203505191000	MUFFLER ASSY	COMPRESSOR ACC	1
70	80203305344000	SUPPORT ASSY	SIDE 1000VF8(A)	2
	80203305344010	SUPPORT ASSY	SIDE 1000VF8(A)SL	2
71	80203305345000	SUPPORT ASSY	FRONT/REAR 1000VF8(A)	2
	80203305345010	SUPPORT ASSY	FRONT/REAR 1000VF8(A)SL	2
72	80223418307003	ANGLE	TOP 1000VF8(A)	2
	80223418307013	ANGLE	TOP 1000VF8(A)SL	2
73	80203418276000	ANGLE ASSY	LEFT BTM 1000VF8(A)	1
	80203418281010	ANGLE ASSY	LEFT BTM 1000VF8(A)SL	1

Service Parts List

No.	Part Code	Part Name	Specification	Quantity
74	80203418272001	ANGLE ASSY	RIGHT BTM 1000VF8	1
	80203418278001	ANGLE ASSY	RIGHT BTM 1000VF8SL	1
75	80202201707000	UNIT BASE ASSY	RIGHT FRONT 1000VF8	1
	80202201707010	UNIT BASE ASSY	RIGHT FRONT 1000VF8SL	1
76	80222201698000	UNIT BASE	LEFT FRONT 1000VF8(A)	1
	80222201698010	UNIT BASE	LEFT FRONT 1000VF8(A)SL	1
77	80222201697000	UNIT BASE	LEFT REAR 1000VF8	1
	80222201697010	UNIT BASE	LEFT REAR 1000VF8SL	1
78	80223218355000	TUBE CAPILLARY		2


Exploded View (OCU-CR1000VF8/OCU-CR1000VF8SL)

OCU-CR1000VF8/OCU-CR1000VF8SL



Exploded View (OCU-CR1000VF8/OCU-CR1000VF8SL)

OCU-CR1000VF8/OCU-CR1000VF8SL



Exploded View (OCU-CR1000VF8/OCU-CR1000VF8SL)

OCU-CR1000VF8/OCU-CR1000VF8SL

